



THE INNOVATORS OF COMFORT™



## Stressless® City Low-Back

Size:

**M**

Chair,

W: 31½"

H: 34¼" - 35¾"

D: 28"



The Stressless City rotates a full 360° and is available with two different seat heights.

Adjust the Stressless Glide wheels to the setting you desire. You can automatically shift to any seating position by simply using your body weight.