



THE INNOVATORS OF COMFORT™



Stressless® Chelsea

Size: Small
Chair, W: 29½" **H:** 39½" **D:** 28¾"
Seat Height: 15¾"
Ottoman: W: 21¾" **H:** 15" **D:** 15¼"

Stressless® Mayfair

Size: Medium
Chair, W: 32" **H:** 40½" **D:** 28¾"
Seat Height: 15¾"
Ottoman: W: 21¾" **H:** 15" **D:** 15¼"

Stressless® Kensington

Size: Large
Chair, W: 35½" **H:** 40½" **D:** 30¼"
Seat Height: 16½"
Ottoman: W: 21¾" **H:** 15" **D:** 15¼"



Adjust the Stressless® Glide wheels to the setting you desire. You can automatically shift to any seating position by simply using your body weight.



The Stressless® Chelsea, Mayfair and Kensington can be adjusted to match your height by adding an elevator ring.