



THE INNOVATORS OF COMFORT™



Stressless® Vision

Size: Small
Chair, W: 31½" **H:** 39½"-43¼" **D:** 30"
Seat Height: 17¾"
Ottoman: W: 22½" **H:** 17¼" **D:** 19¾"

Stressless® Dream

Size: Medium
Chair, W: 33¼" **H:** 39¾"-43¾" **D:** 32¼"
Seat Height: 18"
Ottoman: W: 22½" **H:** 17¼" **D:** 19¾"

Stressless® Spirit

Size: Large
Chair, W: 36¼" **H:** 39¾"-43¾" **D:** 32¼"
Seat Height: 18"
Ottoman: W: 22½" **H:** 17¼" **D:** 19¾"



Adjust the Stressless® Glide wheels to the setting you desire. You can automatically shift to any seating position by simply using your body weight.



The Stressless® Vision, Dream and Spirit can be adjusted to match your height by adding an elevator ring.